

Smoke-Evac Fusion Treatment System

- 1) Insert posts (B) into base (A).
- 2) Secure posts by installing washer and inserting bolts through the bottom of the base into posts, and tighten.
- 3) Attach electrosurgical unit to upper support tray.
- 4) Use hooks on back side of smoke evacuator to hang from metal loop holds located on the cart posts

**FEDERAL (USA) LAW RESTRICTS
THIS DEVICE TO USE BY OR ON
THE ORDER OF A PHYSICIAN.**



3540 Soquel Ave. Suite B, Santa Cruz, Ca. 95062
800-459-1389 . www.zinnantisurgical.com

